



FOR FLIGHT SIMULATION USE ONLY

## Airbus A3XX Series Checklists

### NORMAL CHECKLISTS

Pre-Flight	Cockpit Preparation	Before Start	After Start
PARKING BRAKE.....ON WEATHER RADAR.....OFF PREDICTIVE WINDSHEAR.....OFF SPOILERS DISARMED & RETRACTED...CHECK FLAPS.....RETRACTED ENGINE MODE SELECTOR.....NORM ENGINE MASTERS.....OFF THRUST LEVERS.....IDLE TRANSPONDER MODE.....STBY ANTI-SKID.....ON LANDING GEAR.....DOWN WIPERS.....OFF BATTERY, above 25V (both).....CHECK	BATTERY 1 AND 2.....ON EXTERNAL POWER.....ON APU & ENG FIRE TESTS.....PERFORM CREW SUPPLY.....ON ADIRS.....NAV COCKPIT LIGHTS.....AS REQ NAV & LOGO LIGHTS.....ON NO SMOKING SIGNS.....ON/AUTO EMERGENCY LIGHTS.....ARM EFB.....SETUP ANNUNCIATOR LIGHTS.....TEST PROBE/WINDOW HEAT.....AUTO ANTI-ICE.....OFF AIR CONDITION.....AS REQ ACCU & BRAKE PRESSURE.....CHECKED ECAM STATUS.....CHECKED ECAM RECALL.....CHECKED RADIO PANELS.....SETUP BARO.....SET QNH / INHG EFIS.....CSTR, ARC, 10NM	WINDOWS AND DOORS....CLOSED & LOCKED APU.....ON APU BLEED.....ON MCDU.....SETUP SQUAWK.....SET EXTERNAL POWER....DISCONNECTED & OFF FUEL PUMPS.....ON SEATBELT SIGNS.....ON THRUST LEVERS.....IDLE FUEL QUANTITY.....CHECKED TAKEOFF DATA.....SET & REVIEWED TRANSPONDER MODE.....AUTO BEACON LIGHTS.....ON ENGINE MODE SELECTOR.....IGN PARKING BRAKE.....AS REQ	PARKING BRAKE.....ON ENGINE MODE SELECTOR.....NORM APU.....OFF AUTO BRAKES.....MAX FLIGHT CONTROLS.....CHECKED SPOILERS.....ARMED FLAPS.....SET PITCH TRIM.....SET RUDDER TRIM.....ZERO ANTI-ICE.....AS REQ FLIGHT INSTRUMENTS.....CHECKED
Taxi	Before Takeoff	Takeoff	After Takeoff
TAXI LIGHT.....ON RUNWAY TURNOFF LIGHTS.....AS REQ STROBES.....AUTO TAKEOFF CONFIG.....NORMAL	CABIN CREW.....ADVISED BRAKE TEMPERATURE.....CHECKED BRAKE FANS.....OFF ENGINE MODE SELECTOR.....AS REQ PACKS.....AS REQ WEATHER RADAR.....AS REQ PREDICTIVE WINDSHEAR.....AUTO TCAS.....TA/RA, ABV NOSEWHEEL LIGHTS.....TO LANDING LIGHTS.....ON ECAM MEMO.....NO BLUE	CHRONO.....START BRAKES.....AS REQ ENGINES.....STABILIZED 40% N1 THRUST.....FLEX/MCT OR TOGA	LANDING GEAR.....RETRACTED ENGINE MODE SELECTOR.....NORM SPOILERS.....DISARMED & RETRACTED THRUST.....CLB FLAPS.....RETRACTED PACKS.....ON ANTI-ICE.....AS REQ NOSEWHEEL LIGHTS.....OFF RUNWAY TURNOFF LIGHTS.....OFF

<b>Climb</b>	<b>Cruise</b>	<b>Descent</b>	<b>Before Landing</b>
BARO.....STD	NAV AIDS.....AS REQ	MCDU LANDING PERF.....REVIEWED	CABIN CREW.....ADVISED
LANDING LIGHTS.....OFF	SEATBELT SIGNS.....AS REQ	TCAS.....BLW	EFIS.....AS REQ
SEATBELT SIGNS.....AS REQ		APPROACH BRIEFING.....COMPLETED	ND TERRAIN.....AS REQ
ANTI-ICE.....AS REQ		ANTI-ICE.....AS REQ	LANDING GEAR.....DOWN
		BARO.....SET QNH / INHG	FLAPS.....SET FOR LANDING
		SEATBELT SIGNS.....ON	SPOILERS.....ARMED
		LANDING LIGHTS.....ON	AUTO BRAKES.....AS REQ
			ENGINE MODE SELECTOR.....AS REQ
			NOSEWHEEL LIGHTS.....TO
			RUNWAY TURNOFF LIGHTS.....ON
			GO AROUND ALTITUDE.....SET
			ECAM MEMO.....LDG NO BLUE

<b>After Landing</b>	<b>Turning to Gate</b>	<b>Parking</b>	<b>Securing the Aircraft</b>
BRAKE FANS.....AS REQ	RUNWAY TURNOFF LIGHTS.....OFF	PARKING BRAKE.....ON	BRAKE FANS.....OFF
LANDING LIGHTS.....OFF	NOSEWHEEL LIGHTS.....OFF	ENGINE MASTERS.....OFF	EMERGENCY LIGHTS.....OFF
NOSEWHEEL LIGHTS.....TAXI		FUEL PUMPS.....OFF	NO SMOKING SIGNS.....OFF
RUNWAY TURNOFF LIGHTS.....AS REQ		BEACON LIGHTS.....OFF	NAV & LOGO LIGHTS.....OFF
SPOILERS.....DISARMED & RETRACTED		SEATBELT SIGNS.....OFF	CREW SUPPLY.....OFF
FLAPS.....RETRACTED		TRANSPONDER MODE.....OFF	ADIRS 1/2/3.....OFF
ENGINE MODE SELECTOR.....NORM		ANTI-ICE.....OFF	COCKPIT LIGHTS.....OFF
TCAS.....STANDBY		EXTERIOR LIGHTS.....AS REQ	APU.....OFF
WEATHER RADAR.....OFF		EXTERNAL POWER.....ON IF AVAIL	EXTERNAL POWER.....OFF
PREDICTIVE WINDSHEAR.....OFF		APU.....OFF IF EXT PWR AVAIL	BATTERIES.....OFF
TERRAIN.....OFF			EFB.....OFF
FLIGHT DIRECTORS.....OFF			
APU.....START			
WING ANTI-ICE.....OFF			
ENGINE ANTI-ICE.....AS REQ			
APU BLEED.....ON WHEN AVAIL			

<b>Go Around</b>
THRUST LEVERS.....TOGA
FLAPS.....ONE NOTCH UP
POSITIVE CLIMB.....GEAR UP
THRUST.....CLB
FLAPS.....RETRACTED
SPOILERS.....DISARM