

### QUICK REFERENCE LIGHT USAGE

		Captain				FO					
		Landing Lights		Other							
		Retract <i>if installed</i>	Fixed	Turn-Off	Taxi	Logo Night Only	Strobe	Anti-Col	Position	Wing	Wheel Well Lights *
TAXI	DAY	OFF	OFF	OFF	OPTIONAL	OFF	OFF	ON	ON	OFF	OFF AFTER START FLOW GND CREW CLEAR
	NIGHT	AS REQ	AS REQ	AS REQ	ON	ON	OFF	ON	ON	OFF	ON AFTER LANDING FLOW
RWY CROSSING		ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
LINEUP & WAIT		OFF	OFF	ON	ON	ON	ON	ON	ON	ON	OFF
TAKEOFF / LANDING		ON *	ON	ON	Takeoff - ON Landing - Optional	ON	ON*	ON	ON	ON	OPTIONAL
FLAPS UP TO FL180		OFF	ON	ON	OFF	ON	ON	ON	ON	ON	OFF
FL180 & ABOVE		OFF	OFF	OFF	OFF	OFF	ON	ON	ON	OFF	OFF

\* CAUTIONS & Notes:

C On the ground, do not use landing or strobe lights when their use may be distracting to other pilots.

C (NG) Do not extend the retractable landing lights when the runway is contaminated with clutter.

N When weather conditions make certain lights distracting, discontinue their use.

N Wheel Well Lights ON for crew change (exterior inspection)